



Acrylic Wall Frame Kit with Magnet Standoffs Installation Guide and Drill Template

SKU: AMS10X125

Package Includes



2 x Acrylics



4 x Magnetic Standoff Set



4 x Screws & Anchors
1 x Allen Key



Got Questions? Call Us!

+1 (813) 938-6025

sales@mbs-standoffs.com

Installation Guide



Place template on wall with tape. Make sure that template is level. Mark the hole locations.



Drill with a 1/4" diameter cobalt drill bit.



Insert supplied anchors into the wall.



Mount the metal washers to the wall.



Remove plastic film from the back of the panels. Center your image onto one of the panels.



Place the magnetic standoffs on to metal washers, Use Allen Key to tighten the screw caps to secure both the panels and image.

mbs-standoffs.com

sales@mbs-standoffs.com

+1 (813) 938-6025

5046 W Linebaugh Ave, Tampa, FL 33624

